


HMW 6.9 PHT-EN



| No | Part List | Code |
|----|--------------------------------|---------|
| 1 | Brake Cover | A046Y10 |
| 2 | Brake Body | A038 |
| 3 | Brake Spring | A044 |
| 4 | Brake Piston | A043Y09 |
| 5 | Brake Disc and Bearing | A032Y08 |
| 6 | Brake Gear | A034 |
| 7 | Body-1 Bearing | A005 |
| 8 | Body-1 | A001 |
| 9 | Manuel Clutch Shifter | A088Y07 |
| 10 | Ring Gear | A006 |
| 11 | Ring Gear Segment and Oil Seal | A008Y12 |
| 12 | Planetary Gear Box | A013Y11 |
| 13 | Spool | A103Y04 |
| 14 | Roller Fairlead | A049Y05 |
| 15 | Cable Tension | A062Y06 |
| 16 | Connection Shaft Kit | A023Y03 |
| 17 | Body-2 Bearing | A020 |
| 18 | Body-2 | A019 |
| 19 | Hydraulic Motor Kit | A079 |
| 20 | Over Center Valve | A082Y01 |
| 21 | Installation Tube | A087Y02 |